



2003-Newer Chevy/GMC Pre-Runner Bar

Installation Instructions:

1. Remove plastic clips/air dam on the underside of front bumper.
2. Temporally install pre-runner bar to the underside of the bumper using the supplied 7/16 bolts, flatwashers and nuts.
3. Mark the 4 holes on the face of the bumper.
4. Remove the bar and drill four 7/16 holes.
5. Re-install the bar using 7/16 hardware on the underside and 3/8 hardware on the face of the bumper.
6. Trim the air dam to fit around the lower tubes and re-install.

If you have any questions or concerns, please feel free to contact us at info@boulderoffroad.com.

